iSound: The New Sound

FULL FREQUENCY WIRELESS FM Transmitter User's Guide

PRODUCT LAYOUT:

1. Power button
2. Optional power input 5V DC (not included)
3. 3.5mm jack
4. Preset buttons
5. Control stick
6. Channel display

Using the FM Transmitter:

1. Open the battery compartment and install 2 "AAA" batteries. Close the battery lid. *Note: you can also purchase a 5V DC adapter at many electronics stores, for optional power.*

2. Connect one end of the included 3.5mm audio cable to your audio device of choice, connect the other end to the FM Transmitter. *Note: the FM transmitter works with any audio device with a standard 3.5mm headphone jack.*

3. Power "ON" the FM Transmitter by holding the POWER button for 3-4 seconds. Follow the same steps to POWER the unit "OFF"

Set up an FM radio source:

1. You use the Full Function FM Transmitter to transmit the audio from your audio device to ANY FM Radio at home or in the Car.

2. On your FM radio, choose a FM radio station, now set the FM Transmitter to the same station that you chose on your FM radio. Press play on your audio device and the audio will be wirelessly transmitted to your FM radio. If you experience poor sound quality, try a different FM radio station.

3. The FM Transmitter can store stations for later use, to store a station press the 1, 2, 3 or 4 button for 3 seconds, the station will flash once to indicate the station was stored. To return to the stored station, press the number for which the station was stored.

FOR TECHNICAL SUPPORT
PLEASE CONTACT: 1-877-999-DREAM
or visit us on the web @ www.isound.net

for all iPod models | for Zune | for PC | for PSP | for all MP3 players

www.isound.net

iSound: The New Sound

i.Sound by dreamGEAR
P.O. BOX 478
Torrance, CA 90508

www.dreamgear.net
www.isound.net